



# ST 5045 CLASSIC HOPSCOTCH

## APPLICATION INSTRUCTIONS

### SIZE

approx. 2 feet 4 inches wide x  
7 feet 5 inches long


### PAINTERS & TIME

1-2 painters for 1-2 hrs




© 2013 Fit and Fun Playscapes, LLC

**INCLUDED IN THE BOX: 1 Stencil Sheet (multiple inserts)**



**BEFORE YOU START PAINTING: Please completely read the General Instructions & prepare your surfaces as recommended.**



## STEP 1:


Remove the numbered squares inserts from your **STENCIL** then put aside.



## STEP 2:

Place your **STENCIL** in your desired location.

Paint your **STENCIL**. Repeat 1-2 more times to achieve desired vividness, drying after each application. Then remove your **STENCIL**.



## STEP 3:

Place the numbered squares inserts over the painted areas. Paint each piece. Repeat 1-2 more times to achieve desired vividness, drying after each application. Remove all stencil inserts.

**Allow the paint to dry for a minimum of 24 hours before use.**



# CONGRATULATIONS!!!

**YOU FINISHED PAINTING CLASSIC HOPSCOTCH  
YOU DID IT! GIVE YOURSELVES A PAT ON THE BACK!**

Your finished Classic Hopscotch should look like the image below.



**Have any questions?** We're here to help – call us at (800) 681-0684!

VISIT OUR WEBSITE AT **[WWW.FITANDFUNPLAYSCAPES.COM](http://WWW.FITANDFUNPLAYSCAPES.COM)**

THIS INFORMATION IS COPYRIGHT MATERIAL. ALL RIGHTS ARE RESERVED. © 2022 FIT AND FUN PLAYSCAPES, LLC.